

INSTRUCTIONS

TO TAKE DOWN—First cock the hammer by opening sliding bolt "A" and letting it snap forward. Then push in on plunger "B" located at rear end of bolt "A"; at the same time pull down on take-down lever "C" and draw bolt back off frame. Be sure and hold lever "C" down all the way until bolt is removed.

TO RE-ASSEMBLE—Pull down on take-down lever "C" and insert front end of bolt on rear of frame, sliding forward as far as the hammer. Depress hammer and push bolt "A" forward to a closed position. Push in on plunger "B" and take-down lever "C" will snap up into place. Caution! Be sure that take-down lever "C" snaps up into place before firing the gun. If take-down lever "C" will not go up, examine portion of plunger "B" just inside of bolt and see if this has become turned so that a solid part is down. If so, this can be easily corrected by twisting with thumb on knurled end until slot is visible at bottom.

TO OPERATE—Fill magazine with .22 short cartridges and insert in handle. Pull slide "A" as far as it will go, then release it, which allows the slide to carry a cartridge into the barrel, after which all that is necessary is to pull the trigger for each shot.

TO FILL MAGAZINE—Do not force cartridges down through lips at top of magazine. Insert head of cartridge at front of magazine and slide backwards, at same time holding down magazine button so as to relieve pressure of magazine spring.