9mm Lugar

COMPLETE INSTRUCTIONS FOR 4-DIE SETS

LEEDELUXE PISTOL DIES

CAUTION

Ammunition reloading can be dangerous if done improperly and should not be attempted by persons not willing and able to read and follow instructions exactly. Children should not be permitted to reload ammunition without strict parental supervision. Always wear safety glasses when reloading and shooting. Ammunition loaded with these tools and data should only be used in modern guns in good condition. We do not accept responsibility for ammunition loaded with these tools or data as we have no control over the manufacture and storage of components or the loading procedure and techniques. Primers and gun powders, like gasoline and matches, can be dangerous if improperly handled or misused.

PREPARE YOUR CASES

Discard cases with defects such as split necks, indications of head separation or anything that would make them unsuitable for reloading.

CARBIDE FULL LENGTH SIZING DIE



SCREW THE FULL LENGTH SIZER in until it touches the shell holder. Raise the ram; tighten the lock ring finger tight.

The decapper is retained by a collet. Should it be overstressed by an obstruction; it simply slides up without damage. To reset, loosen the decapper clamp and position the decapper flush with clamp end and retighten. Considerable torque may be necessary. A ½" and ¾" wrench are necessary.

PRIME

The Lee Auto Bench Prime

The easiest, most convenient way to prime is with Lee Priming Tools. Never touch primers from box to shell; uses inexpensive priming tool shell holders—no need to endlessly swap between your press shell holder and your priming tool. Includes priming assemblies for large and small primers—change primer size in seconds.



POWDER FUNNEL Order #90190



IMPORTANT! REMOVE ANY RESIDUAL OIL
IN THE THROUGH HOLE OF THE EXPANDING PLUG WITH A TISSUE.

Screw the die in until it touches the shell holder; then back out one full turn. For magnum cases, back out the expander die an additional 13/4 turns. Finger tighten the lock ring, adjust the flare to your liking; turning inward increases the flare. For maximum case life, flare only enough to easily accept a bullet. In use, the expander plug travels approximately 3/e" within the die and comes to an abrupt stop at extraction. This helps to shake the powder through. However, we recommend you check to be sure all the powder has cleared the funnel and expander plug.

Be sure to occasionally clean the bullet lube from the expander plug to prevent a powder clog.



CHARGE THE CASE

Select a load from the chart on reverse side. This is the most critical decision you must make. An overcharge can blow up the gun and injure the shooter or persons nearby. It is dangerous to use a bullet of a greater weight with a charge for a lighter bullet. Never select a load intended for a bullet lighter than you are using. Loads for a slightly heavier bullet are safe. Always start with the STARTING LOADS. You may work up to the NEVER EXCEED LOADS gradually, provided you know how to watch for pressure signs. The Lee Dipper is the safest and easiest powder measure to use. For the ultimate in speed, convenience and versatility, consider the LEE AUTODRUM POWDER MEASURE.



CAUTION After charging the case, the only operation that should be done is to seat the bullet. Never try to seat a primer after powder has been added.





BULLET SEATING DIE

Raise the ram to the top of its stroke and hold. Screw the bullet seating die in until it touches the shell holder; then back it out three full turns. For magnum cases, back out the bullet seating die an additional 1¾ turns. Lightly finger tighten the lock ring. Bullet depth is adjusted by screwing the adjusting screw in or out to suit.

Bullets should be seated deep enough to work through the gun's action. See MAXIMUM OVERALL LENGTH on charge table. If a crimp is desired, screw the die in slightly and test until the proper crimp is formed. Cases must be trimmed to the same length to provide a uniform crimp. Excessive crimp causes the bullet seater to deform soft nose bullets.

Your die set includes the LEE BULLET FEED AND SEAT DIE for use With the LEE AUTOMATIC BULLET FEEDER. It has a 45° chamfer to allow for the mechanical feed fingers and improved operator clearance.

CAUTION Seating bullets excessively deep will reduce the case capacity and increase the pressure. It is extremely important that full wadcutter bullets be used with light loads only. You can select these by their reduced velocity.



CARBIDE FACTORY CRIMP DIE CRIMP AND POST SIZE CASES

Screw the LEE CARBIDE FACTORY CRIMP DIE in, until it just touches the shell holder and back out the adjusting screw. With the loaded round in the die, turn the adjusting screw in until you can feel it just touch the case mouth. Then move the cartridge out of the die slightly and screw the adjusting screw in ½ turn for a light crimp and one full turn for a heavy crimp. You can adjust for even greater crimp and never have to worry about buckling the case as with conventional crimpers. The case is sized as it enters the die and again as it is pulled out of the die. This assures you every case will freely chamber in any standard gun. Don't expect the carbide sizer to touch every case. It is a fail safe tool for the occasional bad round that could ruin your day.

The Bullet Seating die is equipped with a floating bullet seating punch for maximum accuracy. It is designed to seat all shapes of bullets with minimum deformation. If you attempt to compress the charge, it may deform the bullet an objectionable amount. It will be necessary to modify the bullet seating punch to fit the bullet. If unable to do it yourself or have it done locally, we can do it for you. Send \$14.00 along with a sample bullet, and order "Custom Seater Plug for Sample Bullet" (\$8.00 bullet + \$6.00 shipping)

FOR A COMPLETE CATALOG, SEND YOUR NAME AND ADDRESS



@ 2020 PRINTED IN U.S.A